



KWS1 - 800/200
KWS1 - 1000/200

KW - Kaltwasser, AG 1 "
WW - Warmwasser, AG 1 "
E - Entlüftung, IG ½ "
Z - Zirkulation, AG ½ "
L1,2,3,4 - Befüllen / Entleeren, IG 1½ "
L0 - Drainage / Entleeren, AG 1½ "
TS1,2,3,4 - Thermosensor / Fühler, IG ½ "
TSS1 - Thermosensor / Fühler, IG ½ "

ES - Elektrostab, IG 1½ "
TR - Thermoregulator
/ Manometer, IG ½ "
T - Thermometer, IG ½ "
VL1 - Solar / Heizung, IG 1½ "
RL1 - Solar / Heizung, IG 1½ "